How to Order?

S -- 5 -- 2 -- 2 -- 1 -- E2 -- 08 -- F

- S: According to SMC VF series
- 5: 5 Port
- 2: 2 position
- 3: 3 position
- 2: 1/4" valve body
- 3: 3/8" valve body
- 1: Single Control
- 2: Double Control
- Voltage: E1 AC110V; E2 AC220V; E4 DC24V; E5 DC12V
- Thread Size: 06: 1/8"; 08: 1/4"; 10: 3/8"
- F: A: Air control; F: Flying leads; D: DIN connector; DL: DIN connector with LED; C: Center Close; P: Center Pressure; E: Center Exhaust

order example:

* S series, 5 Port, 2 position, 1/4" body, single control with flying leads, AC220V, 1/4" thread size, Model: S5221E2–08F
* S series, 5 Port, 2 position, 3/8" body, double control, 3/8" thread size, air control, Model: S5232–10A

Model:
S5221–06F
S5221–08F
S5231–08F
S5231–10F

Model:
S5221–06D
S5221–08D
S5231–08D
S5231–10D

Model:
S5221–06DL
S5221–08DL
S5231–08DL
S5231–10DL

Model:
S5222–06F
S5222–08F
S5232–08F
S5232–10F

Model:
S5222–06D
S5222–08D
S5232–08D
S5232–10D

Model:
S5222–06DL
S5222–08DL
S5232–08DL
S5232–10DL

Model:
S5322–06FC/S5322–08FC
S5322–06FE/S5322–08FE
S5322–06FP/S5322–08FP
S5332–08FC/S5332–10FC
S5332–08FE/S5332–10FE
S5332–08FP/S5332–10FP

Model:
S5322–06DC/S5322–08DC
S5322–06DE/S5322–08DE
S5322–06DP/S5322–08DP
S5332–08DC/S5332–10DC
S5332–08DE/S5332–10DE
S5332–08DP/S5332–10DP

Model:
S5322–06DLC/S5322–08DLC
S5322–06DLE/S5322–08DLE
S5322–06DLP/S5322–08DLP
S5332–08DLC/S5332–10DLC
S5332–08DLE/S5332–10DLE
S5332–08DLP/S5332–10DLP

Model:
S5221–06A
S5221–08A
S5231–08A
S5231–10A

Model:
S5222–06A
S5222–08A
S5232–08A
S5232–10A

Manifold
S522–NF
(N=1,2,3,.....14)
S523–NF
(N=1,2,3,.....14)